

## Edge of Arlington Saw & Tool, Inc.

124 South Collins  
 Arlington, TX 76010  
 Phone: 817-461-7171 • Fax: 817-795-6651  
 Toll Free: 888-461-7171  
 Email: [info@eoasaw.com](mailto:info@eoasaw.com)  
 Website: [www.eoasaw.com](http://www.eoasaw.com)



TOOLS



CUTS



### Item #SD206, Freud 6 in Dia, 5/8 in Arbor, 10 Tooth SD200 Pro Dado Set **\$122.01**

Thank you for shopping with us! **Application: A Stacked Dado For Flat Bottom Grooves & Virtually Splinter-Free Cuts** Freud's quality and craftsmanship in a stacked dado set, but at a wobble dado price! The negative hook angles make flat bottom grooves and virtually splinter-free cuts. It has two outside blades with three 2-wing chippers. This makes it ideal for underpowered saws because it requires less power to feed. All blades and chippers come with Freud's anti-kickback design. This resharpenable set will produce grooves from 1/4" to 7/8" in 1/16" increments. This dado set comes with a shim set and carrying case as well as instructions on how to make basic dado sizes. Set includes: 2 blades, spacers, shim set, and 3 chippers.

**A Stacked Dado For Flat Bottom Grooves and Virtually Splinter-Free Cuts**

**Application**

**Recommended Use & Cut Quality**

HARDWOOD: Excellent  
 SOFTWOOD: Good  
 CHIP BOARD: Fair  
 PLYWOOD: Fair  
 LAMINATE: Not Recommended  
 NON-FERROUS: Not Recommended

**CUT QUALITY:** Fair → Good → Excellent  
 (Not recommended for ferrous metals or masonry)

Freud's quality and craftsmanship in a stacked dado set, but at a wobble dado price! The negative hook angles make flat bottom grooves and virtually splinter-free cuts. It has two outside blades with three 2-wing chippers. This makes it ideal for underpowered saws because it requires less power to feed. All blades and chippers come with Freud's anti-kickback design. This resharpenable set will produce grooves from 1/4" to 7/8" in 1/16" increments. This dado set comes with a shim set and carrying case as well as instructions on how to make basic dado sizes.

**Set Includes:**

2 Blades

Spacers

Shim Set

3 Chippers

Caution: Carbide tips should never come into contact with each other. Always use both outside blades and never use chippers alone or with just one outside blade.

Item	Dia.	Teeth	Arbor	Chippers(C)	Slot Width	No. Chippers 1/8	Required Spacers
SD206	6"	10	5/8"	(3)1/8"	1/4"	0	0
SD208	8"	12	5/8"	(3)1/8"	5/16"	0	1
					3/8"	1	0
					7/16"	1	1
					1/2"	2	0
					9/16"	2	1
					5/8"	3	0
					11/16"	3	1
					3/4"	4	0
					13/16"	4	1

**Carbide Grade Chart**

← Increasing Hardness (H3BS to H8MX) →  
 ← Increasing Impact Strength →

**Tips & Techniques**

Use a sacrificial backer board to eliminate blow out at the end of your dado cuts

SPECIFICATIONS	
<b>Manufacturer</b>	Freud Tools
<b>Diameter</b>	6 in
<b>Arbor</b>	5/8 in
<b>Note</b>	

## SPECIFICATIONS

<b>Teeth</b>	10
<b>Thickness</b>	(3) 1/8 in Chippers