

Edge of Arlington Saw & Tool, Inc.

124 South Collins

Arlington, TX 76010

Phone:817-461-7171 • Fax: 817-795-6651

Toll Free: 888-461-7171

Email: info@eoasaw.com

Website: www.eoasaw.com



TOOLS



CUTS



Item #SD308, Freud SD300 Safety Dado Sets

\$192.03

Thank you for shopping with us! Freud's Safety Dado Sets provide the highest quality results while maintaining a superior level of safety. This stacked dado set with its razor sharp outside blades will produce grooves or rabbets that are flat-bottomed and virtually splinter-free in solid woods. Stacked dado sets are more precise than other styles and with the use of Freud's Shim Set, the kerf width can be adjusted by as little as .004" for the correct fit. Use on all table saws and radial arm saws for cutting slots, grooves, dados, and rabbets in softwood or hardwood. Set includes 2 blades, shim set, and 5 chippers.

Safe And Splinter Free Dados

Recommended Use & Cut Quality

HARDWOOD:	Excellent
SOFTWOOD:	Good
CHIP BOARD:	Fair
PLYWOOD:	Fair
LAMINATE:	Fair
NON-FERROUS:	Not Recommended

CUT QUALITY: Fair → Good → Excellent
(Not recommended for ferrous metals or masonry)

Freud's Safety Dado Sets provide the highest quality results while maintaining a superior level of safety. This stacked dado set with its razor sharp outside blades will produce grooves or rabbets which are flat-bottomed and virtually splinter-free in solid woods. Stacked dado sets are more precise than other styles and with the use of Freud's Shim Set the kerf width can be adjusted by as little as .004" for the correct fit. Use on all table saws, and radial arm saws for cutting slots, grooves, dados, and rabbets in softwood or hardwood.

Application

Set Includes:

- 2 Blades
- Shim Set (for slots and dados)
- 5 Chippers

Caution: Carbide tips should never come into contact with each other. Always use both outside blades and never use chippers alone or with just one outside blade.

Item	Dia.	Teeth	Arbor	Chippers(C)
SD306	6"	18	5/8"	(4)1/8", (1)1/16"
SD308	8"	22	5/8"	(4)1/8", (1)1/16"

Slot Width	No. Chippers Required 1/8"	No. Chippers Required 1/16"
1/4"	0	0
5/16"	0	1
3/8"	1	0
7/16"	1	1
1/2"	2	0
9/16"	2	1
5/8"	3	0
11/16"	3	1
3/4"	4	0
13/16"	4	1

• Carbide Grade Chart •

Increasing Hardness: H30S, H20S, H18S, H15S, H10S, H08K, H06X

Increasing Impact Strength: ← H30S, H20S, H18S, H15S, H10S, H08K, H06X →

Tips Techniques

To determine if you need a 6" or 8" dado, first consult your saw owner's manual. Even if the manual states that the saw will accept an 8" dado, using the 6" on most 120v saws will greatly reduce the load on the motor.

SPECIFICATIONS

Manufacturer	Freud Tools
Diameter	8 in
Arbor	5/8 in
Teeth	22
Thickness	(4) 1/8